

商品ID	SKU编码	商品名称	69码	产品型号
58247	BHR8974TH	小米自带线充电宝20000mAh 33W 东南亚版 瓷白	6941812795668	PB2030MI
58250	BHR8977TH	小米自带线充电宝20000mAh 33W 东南亚版 晴空蓝	6941812795606	PB2030MI

英

Please read this manual carefully before using the product and keep it properly.

Product Overview

Thank you for choosing Xiaomi ES5W Power Bank 20200mAh (Integrated Cable). This compact and portable power bank supports 30 W two-way fast charging and over 33 W discharging for smartphones that support fast charging. It features a high-quality lithium-ion battery and a charging/discharging chip with excellent performance in superior safety, efficiency, and compatibility.

The battery level check button is not a power button. The power bank detects charging and discharging automatically.

Safety: This power bank is designed based on multiple safeguarding technologies to prevent issues such as overcharging, over-discharging, overheating, and short circuits.

Fast charging: The USB-A port supports charging mode under 5 V/3 A, 9 V/2.25 A, 10 V/2.25 A, and 12 V/1.67 A max; the USB-C port supports charging mode under 5 V/3 A, 9 V/2 A, 11 V/2 A, 12 V/2 A, 15 V/2 A, and 20 V/1.5 A max. Compatibility: The built-in USB charging controller is compatible with most smart devices including smartphones, and tablets.

Quality: A high-quality lithium-ion battery and a durable charging and discharging chip.

Charging

The power bank supports smart temperature control. If you frequently plugging/unplugging a device into/from the power bank during fast charging, it may result in temperature detection errors. Therefore, it is recommended to continuously charge your devices, rather than frequently plugging/unplugging it into/from the charging port.

Use a Xiaomi charger and charging cable to charge the power bank via the USB-C port, or charge it via the integrated USB-C cable on the power bank and a Xiaomi charger. During charging, the battery level information is indicated by the battery level indicators as follows:

Battery Level	LED1	LED2	LED3	LED4
Under 20%	Off	Off	Off	Off
0-25%	Blinking	Off	Off	Off
25-50%	Blinking	Blinking	Off	Off
50-75%	Blinking	Blinking	Blinking	Off
75-100%	Blinking	Blinking	Blinking	Blinking

*Low-current discharge: When the power bank is not being charged, double press the battery level check button to enter the low-current discharge mode. This mode can be used to continuously charge low-current devices such as Bluetooth headphones and smart bands. The indicators will light up in sequence to indicate the power bank is in low-current discharge mode. Simply press the button again to exit this mode. The power bank will automatically exit this mode after 2 hours.

Specifications

Battery Level	LED1	LED2	LED3	LED4
0-25%	Blinking	Off	Off	Off
25-50%	On	Blinking	Off	Off
50-75%	On	On	Blinking	Off
75-100%	On	On	On	Blinking

Charging port: Blinking, Blinking, Blinking, Blinking

Input: Model: P202302A Battery Type: Lithium-ion battery
 Input Port: USB-C/Integrated USB-C Cable
 Output Port: USB-C/Integrated USB-C Cable/USB-A
 Cell Capacity: 10000 mAh ± 4 V
 Typical Battery Energy: 75.48 Wh
 Rated Battery Energy: 74 Wh
 Input: Integrated USB-C Cable (In) 5 V 3 A 9 V 2.5 A 12 V 2.5 A
 USB-C (In/2) 5 V 3 A 9 V 2.5 A 12 V 2.5 A

Discharging

The power bank uses a USB-A/USB-C port or the integrated USB-C cable for charging other devices. During discharging, the battery level information is indicated by the battery level indicators as follows:

Battery Level	LED1	LED2	LED3	LED4
Under 20%	Off	Off	Off	Off
0-25%	Blinking	Off	Off	Off
25-50%	Blinking	Blinking	Off	Off
50-75%	Blinking	Blinking	Blinking	Off
75-100%	Blinking	Blinking	Blinking	Blinking

*Low-current discharge: When the power bank is not being charged, double press the battery level check button to enter the low-current discharge mode. This mode can be used to continuously charge low-current devices such as Bluetooth headphones and smart bands. The indicators will light up in sequence to indicate the power bank is in low-current discharge mode. Simply press the button again to exit this mode. The power bank will automatically exit this mode after 2 hours.

Precautions

- Please reuse fully charge the power bank on its first use.
- Use a USB-C cable and charging cable that Xiaomi-brand ones with conforming specifications are recommended to charge the power bank or use the power bank to charge other devices.
- If the battery level indicators do not light up after pressing the battery level check button, it may be because the power bank is in protective mode. Charge the power bank with a charger and charger.
- When the power bank will not be used for an extended period of time, store it in a cool and dry place, with a battery level of about 50%. For long-term storage, do not fully charge the power bank or leave the battery level empty to avoid reducing its battery life.

Output: 33 W Max. Multi-port: 5 V 3 A
 Integrated USB-C Cable (Output) 5 V 3 A, 9 V 3 A, 11 V 3 A, 12 V 2.5 A, 15 V 2 A, 20 V 1.5 A Max
 USB-C (OUT/2) 5 V 3 A, 9 V 3 A, 11 V 3 A, 12 V 2.5 A, 15 V 2 A, 20 V 1.5 A Max
 USB-A (OUT/3) 5 V 3 A, 9 V 2.25 A, 10 V 2.25 A, 12 V 1.67 A Max
 Operating Temperature: 5°C to 35°C
 Storage Temperature: 0°C to 40°C
 Item Dimensions: 127 × 70.5 × 30.5 mm
 Charging Time: Approx. 9.5 h via 5 V 2.5 A charger
 Approx. 3.6 h via 12 V 2.5 A charger

WARNINGS

Improper use may result in battery failure, overheating, or even fire or exploding. In order to avoid harm to your personal safety and property, please keep and use this product strictly in accordance with the following requirements:

- This power bank is not a toy. Please keep it away from children. Do not let children use or play with this power bank. This power bank is not to be used.
- Make sure you use a charger that complies with the local safety standards when charging this product. In order to prevent an electric shock or damage to the product, do not expose this power bank to pressure, impact, strong vibrations, or liquids. Any of these occurrences may lead to a short circuit or cause damage to the battery or electrical circuit. If this happens, stop using the power bank immediately, and dispose of it properly.
- When the power bank becomes swollen, deformed, starts to leak, or its capacity is significantly reduced, please stop using it immediately and dispose of it properly.
- Do not charge or discharge this power bank in places where its heat dissipation may be affected, such as in the pocket of your pants, a closed bag, or on a bed or sofa. Ensure the power bank is not covered by clothing, pillow, bedding, or other miscellaneous items during its working. When using the power bank to charge devices including phones for an extended period, do not touch them together to ensure better heat dissipation.
- Do not disassemble, cut, squeeze, puncture, short-circuit the power bank or expose it to liquids, fire, heat sources such as stoves, heaters, or an environment with an ambient temperature higher than 60°C (140°F). If neither, do not leave this power bank in a car or outdoors or other places under direct sunlight.
- This power bank contains a lithium-ion battery. Opening the casing is strictly prohibited so as to avoid battery damage or safety hazards.
- Do not replace the battery by yourself. Replacing the battery with the wrong type may result in a failure of safety protection, causing an explosion or fire.

EU Declaration of Conformity

The manufacturer hereby declares that this equipment is in compliance with the applicable Directives and European Norms, and amendments. The full text of the EU Declaration of conformity is available at the following internet address: <http://www.mi.com/global/en/ce/svc/support/declaration.html>

WEEE Information

All products bearing this symbol are waste electrical and electronic equipment (WEEE) as in directive 2012/19/EU which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

Manufactured by: Dongguan DSE Energy Technology Co., Ltd.
 For further information, please go to www.mi.com
 User Manual Version: V1.0

1 2 3 4 5 6

泰语

印尼语

[illegible]

小米生态链产品包装图纸

图纸提供单位

北京米物科技有限公司

项目名称

小米自带线充电宝20000mAh 33W
东南亚版 说明书

版本号

V2.0 加原产国信息

红色标注仅为字稿修改区分提醒,大货请注意统一颜色

设计时间

2024.07.11

设计师

王冉

材质工艺要求

材质要求: 60g双胶纸

制作工序

印刷+折页+骑马订装

工艺要求

模切走位 $\leq \pm 0.5\text{mm}$

颜色及 专色: PANTONE Cool Gray 11 C

纹理要求

比例 1:1 单位 mm



Diimpor oleh: PT. Xiaomi Communications Indonesia
One Pacific Place Suite 9-H I L K II Jendral Sudirman

Kav.52-53 Lot 3&5, Jakarta Selatan 12190, Indonesia
Disediakan oleh: Deenggoan DBK Energy Technology Co., Ltd.

Untuk informasi selengkapnya, kunjungi www.mi.com

Versi Panduan Pengguna: V1.0
Dibuat di Tiongkok
